MEASURE WITH PRECISION

www.sew.com.tw

5F., NO.105, Jhongcheng Rd., Tucheng Dist., New Taipei City 23674, Taiwan (R.O.C.) TEL: 886-2-22681528 FAX: 886-2-22681529 e-mail: sales@sew.com.tw



2120 ER

3 Wire Earth Resistance Tester



FEATURES

- Capable of measuring earth resistance and earth voltage.
- 2mA measuring current permits the testing of earth resistance without tripping earth leakage current breakers in the circuit under test.
- The leads are supplied as standard accessories for simplified two-wire measuring system.
- Battery operated.
- Data hold function.
- Low battery indication.
- Calibration performed with supplied test leads.

SPECIFICATIONS

	Earth resistance 0-20Ω / 0-200Ω / 0-2000Ω
Measuring ranges	Earth voltage
	0-200 Vac (40-500Hz) Earth resistance ±(2%rdg+2dgt)
Accuracy	or $\pm 0.1\Omega$, which is greater Earth voltage $\pm(1\%rdg+2dgt)$
Earth resistance resolution	0-20Ω : 0.01Ω 0-200Ω : 0.1Ω 0-2000Ω : 1Ω
Measuring system	Earth Resistance by constant current inverter 820Hz approx. 2mA.
Display	31/2 digit (2000 counts)
Open circuit indication	LED will be unlit
Low battery indication	" 🕂 "symbol appears on the display
Data hold indication	" HOLD "symbol appears on the display
Over range Indication	"1"(MSD)
Dimensions	170(L) × 165(W) × 92(D)mm
Weight (battery included)	Approx. 1040g
Power source	1.5V (AA) × 8
Safety standard	EN 61010-1 CAT II 300V IEC 61557-1 IEC 61557-5 EN 61326-1
Accessories	Instruction manual Test leads (red-15m, yellow-10m, green-5m) Shoulder belt Auxiliary earth spikes Simplified measurement probe Batteries

FEATURES

CE

- Capable of measuring earth resistance and earth voltage.
- 2mA measuring current permits the testing of earth resistance without tripping earth leakage current breakers in the circuit under test.
- The leads are supplied as standard accessories for simplified two-wire measuring system.
- 0Ω adjustment.
- Battery operated.
- Data hold function.
- Low battery indication.
- Calibration performed with supplied test leads.

SPECIFICATIONS

Measuring ranges	Earth resistance $0-20\Omega / 0-200\Omega / 0-200\Omega$ Earth voltage 0-200 Vac (40-500Hz) Earth resistance $\pm (2\%\text{rdg}+2\text{dgt})$
Accuracy	or $\pm 0.1\Omega$, which is greater Earth voltage $\pm (1\%rdg+2dgt)$
Earth resistance resolution	0-20Ω : 0.01Ω 0-200Ω : 0.1Ω 0-2000Ω : 1Ω
Measuring system	Earth Resistance by constant current inverter 820Hz approx. 2mA.
Display	3 ¹ / ₂ digit (2000 counts)
0Ω adjustment	\checkmark
Open circuit indication	LED will be unlit
Low battery indication	" 🕂 "symbol appears on the display
Data hold indication	" HOLD "symbol appears on the display
Over range Indication	"1"(MSD)
Dimensions	210(L) × 210(W) × 100(D)mm
Weight (battery included)	Approx. 1395g
Power source	1.5V (AA) × 8
Safety standard	IEC/EN 61010-1 CAT III 200V. IEC 61557-1 IEC 61557-5 EN 61326-1
Accessories	Instruction manual Test leads(red-15m, yellow-10m, green-5m) Auxiliary earth spikes Simplified measurement probe Carry case Batteries